

# INSTALLATION INSTRUCTIONS



## SHOWER

## ACRYLIC SHOWER TRAY WITH TILED WALL



PLEASE FOLLOW THESE GUIDELINES WHEN INSTALLING TILED WALLS WITH YOUR ENGLEFIELD SHOWER TRAY AND DOOR.

IF IN DOUBT, CALL OUR AFTER-SALES SERVICE TEAM FOR GUIDANCE.

1. Discuss the installation and tiling with your chosen waterproofing / tiling professional and Approved Englefield Installer prior to starting.
2. Follow both the Englefield Acrylic Shower Tray and wall board manufacturer (eg. GIB®, Villaboard® or other) instructions when installing the shower tray and wall board.
3. If possible, the complete door system should be installed onto the cured waterproof membrane prior to wall tiling.

**AT A MINIMUM THE VERTICAL WALL RETAINER EXTRUSIONS MUST BE INSTALLED ONTO THE CURED WET AREA MEMBRANE PRIOR TO WALL TILING.**

Failure to do so may mean that the door system may not fit on the shower tray due to a combination of tile thickness, tile adhesive thickness and any positive / negative inclination of the finished wall board.

**PLEASE REFER TO SHOWER DOOR INSTALLATION INSTRUCTIONS FOR ANY TILE CLEARANCES THAT NEED TO BE OBSERVED.**

4. Fill any screw holes that penetrate the waterproof membrane with silicone sealant. Defer to any further recommendations of your chosen waterproofing / tiling professional regarding this.

## CONTACT INFORMATION

**NEW ZEALAND**  
KOHLER NZ LTD

Free Ph: 0800 100 382  
Free Fax: 0800 664 488  
[www.Englefield.co.nz](http://www.Englefield.co.nz)

**AUSTRALIA**  
KOHLER CO.

Free Ph: 1 800 ENGLEFIELD  
(1 800 364 533)  
[www.Englefield.com](http://www.Englefield.com)