Caroma[®]

INSTALLATION PROCEDURE FOR LIANO WALL HUNG PAN

VITREOUS CHINA LIANO WALL HUNG PAN

PLUMBERS INSTALLATION INSTRUCTIONS PLEASE READ CAREFULLY BEFORE INSTALLATION


NOTE - Installation must be on a non-compressible wall material.

- 1 Install Caroma bracket and pipework to specified dimensions, as detailed in Fig. 3.
- 2- Ensure the contact area on the wall for fitting the pan is flat and true. Check with straight edge before installation.
- Set the length of the fixing studs 38mm from the finished wall surface, as detailed in Fig. 1.
- Set the inlet pipe to 29mm from the finished wall, as detailed in Fig. 4.
- Fit keeseal onto the inlet pipe.
- Remove paper cover from gasket and stick gasket to the back of the pan ensuring it is centralised.
- Fit rubber gasket into position.
- Fix the mounting sleeves onto fixing studs so that 10mm of thread is exposed in front of the gasket, as detailed in Fig. 1.
- Make sure the fixing notch in the sleeves are facing outwards towards the fixing holes in the pan.
- 10- Fit the plastic fixing bushes into the holes provided with the grub screw facing the fixing holes in the side of the pan, as detailed in Fig. 2.
- 11- Smear pan collar and inlet keeseal with soap solution for push on installation of pan.
- 12- Install the pan onto the fixing sleeves ensuring engagement onto the inlet pipe and pan collar and hold in position.
- 13- Insert fixing key through the fixing holes in the side of the pan and tighten the grub screws to a maximum torque 7Nm[62 lbf-in] on both sides to hold the pan onto the bracket.
- 14- Fit toilet seat.
- 15- For optimum installation, it is recommended that the joint between the pan and finished wall be caulked with acetic cured silicone sealant.


INCLUDED:


- D.990 Fixing kit
- Rubber Gasket (1)
- 50mm Keeseal

Fixing Detail Rubber Inlet keeseal gasket Inlet pipe Sleeve Fixing bush outwards Fig. 1









All measurements are subject to accepted manufacturing tolerances.

To ensure accuracy please check actual product dimensions before drilling for installation.